




---

Quick Reference

---

## Instrument - Overview



# Buttons - Overview



Device ON/OFF	
<b>Short push</b>	Power ON
<b>Long push (&gt;5s)</b>	Power OFF


  

Operation	
<b>Short push</b>	Scroll right, select, adjust
<b>Long push (&gt;1.4s)</b>	Start new series (Store current series and start new series) Operation possible at any time



Operation	
<b>Short push</b>	Scroll down
<b>Long push (&gt;1.4s)</b>	Backlight on/off
<b>Long push (&gt;5s)</b>	Power OFF

## Main Screen - Overview



# Main Menu - Overview

## Mode

### Configuration of operation mode

LIVE using the app  
PRINT using a BT printer

## Standard

### Select standard

ASTM → Rebound value according to ASTM D5873  
ISRM → Rebound value according to International Societ of Rock Mechanics  
WG → Weathering Grade according to ISRM  
MEAN  
MEDIAN

## Memory

Clear memory

## Info

Show device information

# Menu - Navigation



HOME/MEASUREMENT screen



## MAIN MENU



### Mode Selection



SCROLL



SELECT



### Standard selection



SCROLL



SELECT/ADJUST



### Clear Memory



SCROLL



SELECT




**Unsynchronized data will be lost**



HOME/MEASUREMENT screen



# Measurements



## Auto-switch off

No activity > 5 minutes →  
Current series is saved  
Current series is closed  
Power off

# Viewing Results

Scroll through results




Return to series



Delete whole series

Start new series



SCROLL




SELECT/ADJUST




# Printing Results

Scroll through results




Return to series



Print series

Delete whole series

Start new series



SCROLL



SELECT/ADJUST



## Further Information

Requires a BT printer → available as accessory

Configuration for printing → [Mode selection](#)

SWISS  MADE

For more information on the product use of the product,  
please refer to the Rock Schmidt RS8000 documentation

It is available for download on



[www.screeningeagle.com/en/  
products/rock-schmidt-rs8000](http://www.screeningeagle.com/en/products/rock-schmidt-rs8000)

**ASIA-PACIFIC**

Proceq Asia Pte Ltd.  
1 Fusionopolis Way  
Connexis South Tower #20-02  
Singapore 138632  
T +65 63823966

**CHINA**

Proceq Trading Shanghai Co., Limited  
Room 701, 7th Floor, Golden Block  
407-1 Yishan Road, Xuhui District  
200032 Shanghai | China  
T +86 21 6317 7479

**EUROPE**

Proceq AG  
Ringstrasse 2  
8603 Schwerzenbach  
Zurich | Switzerland  
T +41 43 355 38 00

**UK**

Screening Eagle UK Limited  
Bedford i-lab, Stannard Way  
Priory Business Park  
MK44 3RZ Bedford  
London | United Kingdom  
T +44 12 3483 4645

**MIDDLE EAST AND AFRICA**

Proceq Middle East and Africa  
Sharjah Airport International  
Free Zone | P.O.Box: 8365  
United Arab Emirates  
T +971 6 5578505

**USA, CANADA & CENTRAL AMERICA**

Screening Eagle USA Inc.  
14205 N Mopac Expressway Suite 533  
Austin, TX 78728 | United States

Screening Eagle USA Inc.  
117 Corporation Drive  
Aliquippa, PA 15001 | United States  
T +1 724 512 0330

**SOUTH AMERICA**

Proceq SAO Equipamentos  
de Medição Ltda.  
Rua Paes Leme 136  
Pinheiros, Sao Paulo  
SP 05424-010 | Brasil  
T +55 11 3083 3889